




POTATO HARVESTER

DOWNLOAD MULTILINGUAL
USER MANUAL




code.ironbaltic.com/u/ziEgPgka

Receiver mount system

Code 84.11000

Version 08012024




Keep this manual for future reference!

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic
sales@ironbaltic.com

Iron Baltic Ltd | +372 653 3711 | sales@ironbaltic.com | www.ironbaltic.com

SPECIFICATION

Pos.	Description	Code	Amount
1	Mounting adapter	84.8001K	1
2	U-bolt 50 mm	84.2010	2
3	Potato digger	OT.52.05.030	1
4	Spring loaded pin 10x60	OT.10.11.011	2
5	Washer M10 DIN125	OT.04.01.040	4
6	Nyloc nut M10 DIN985	OT.03.02.050	4



FITTING INSTRUCTIONS





Potato harvester is designed with safety in mind. In order to protect you and your ATV, certain parts of the product and/or its hardware may fail when equipment is over-stressed. For this reason, mounting adapter, adapter clamp and pin are not covered by warranty.

Step 1

Install mounting adapter (Pos.1) to the receiver mounting system tool holder and fasten with the u-bolts (Pos.2), Ø10 mm washers (Pos.5) and M10 nyloc nuts (Pos.6)! Then fasten the plough (Pos.3) to the adapter, use the spring loaded pin (Pos.4) for fastening.

NB! The mounting adapter must be in front of the tool holder!



IRON BALTIC

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticLtd

